

Complementary products



BXAD Adapter

The BXAD adapter has been developed for use with the various versions of model BX, MBX and HX and it is placed between the body and the nozzle holder. The adapter allows placing an anti-drip valve before the nozzle holder.

That has the advantage that the orifice insert and core can be replaced without the supply line being drained.



RXAD Adapter

The RXAD adapter has been developed for use with model RX and it is placed between the body and the nozzle holder. The adapter allows placing an anti-drip valve before the nozzle holder.

That has the advantage that the orifice insert and core can be replaced without the supply line being drained.



CRXAD Adapter

The CRXAD adapter has been developed for use with various versions of model RX. To facilitate cleaning, the adapter is screwed into the body in the place of the nozzle holder.

The adapter makes it possible to connect the lance with the RX body to the camlock coupling of the CIP installation after a production run.



QCRX-AD Adapter

The QCRX-AD adapter is intended for use with model QRX. To facilitate cleaning, the adapter is coupled to the camlock coupling. The adapter makes it possible to connect the lance with the quick-connect coupling to the camlock coupling of the CIP installation after a production run.



CBXS Body

This body from the BX series has the shape of a camlock coupling and after a production run it can be connected complete with lance to the CIP installation. The body is available with a weld-on connection, 1/4" or 3/8" female thread connection.



Lecithin nozzle

This special air atomizing nozzle with wear resistant air cap is available in various capacities and connections.

In the nozzle's mixing chamber lecithin is mixed with steam. That produces a very fine lecithin mist.